



Guard Foot Location for Kits using
Top Plates B-166, B-224, and B-439
Number is on bottom of Top Plate

Two 9/32" Dia. Holes
1 9/16" Apart on Each Side

5/8" Dia. Hole - for Wires
Each Side - If Guard has Electronics

Instructions

1. Cut along Green Dotted Line around Pedestal.
2. Discard Center Section.
3. Mark Center of Forward Side of Pedestal Base - 3" from Bolt Centers
4. Align Template on Pedestal using CenterMark & Bolt Marks.
5. Mark 4 Holes for Appropriate Guard Foot Bolts.
6. Remove Template and Drill 4 9/32" Dia. Holes for Bolts.
7. Thru-Bolt Guard Feet with Supplied Bolts, Using Oil-Based Bedding Compound to Seal Holes.

Use ONLY oil base bedding compound for bedding these nylon feet. Silicone bedding materials have, at times caused damage to plastics. Clean excess Only with turpentine, mineral spirits, or equivalent. Acetone, MEK, carbon tetrachloride, and similar solvents will cause discoloration to the guard feet.