



Parts included:

Two piece ball mount, cap and threaded section. **Hollow mounting bolt** One 1 1/4" to 1" bushing One 1 1/4" to 1 1/8" bushing Two 1/4-20 allen head screws Two large rubber washers One large plastic washer

1. Position the appropriate bushing (if required) on the rail in the location for your instrument housing. Clamp the ball mount on the bushing. Using a punch, mark the rail location for the wiring hole. Drill a hole for the wiring.



2. Drill a 1 1/18" hole using a hole saw in the instrument housing.









