

1. 960-G-230-A (Brake Shaft and Knob)
2. 960-B-1217 (Bearing Holder)
3. F1032-3/4-SC (Retaining Screws for Bearing Holder)
4. 960-A-1933 (O-Ring)
5. 960-A-140-1.1 (Needle Bearing 1 1/8")
6. 960-A-1727 (Retaining Ring)
7. 684-187W (Woodruff Key - Half Circle)
8. 960-A-2353 (Brake Shoe)
9. 960-A-2069 (Cross Pin for Through Shaft Brake - 2 5/8")
10. 960-B-1176 (Tapered Wheel Shaft)
11. 684-250W (Shaft Key - 1/4" x 1/4" x 1 1/2")
12. 960-A-2105 (Star Wheel Nut)
13. 960-A-2026 (Black Spacer)
14. 960-A-2323 (Stainless Washer)
15. 960-A-1870 (Spiral Snap Ring)
16. 960-A-2715 (Clamp-On Shaft Collar)
17. 855-2-11-TSB (Double Hub Sprocket)
18. 960-A-3172 (Black Spacer Bushing)

