


Steering Data Sheet



US 42
(BAYLINER)

S-1013

THIS SCHEMATIC IS INTENDED TO PROVIDE AN OUTLINE FOR DESIGNING YOUR SYSTEM. COMPLETE INSTRUCTIONS FOR INSTALLATION CAN BE FOUND IN OUR "PLANNING & INSTALLATION GUIDE", WHICH CAN BE FOUND ONLINE.



VISIT US ONLINE AT
WWW.EDSONMARINE.COM

AFT STATION:

- 1 FIG. 336-5-211T 1
- 1 FIG. 647ST-30-5
- 1 FIG. 77209
- 1 FIG. 799-2
- 2 FIG. 797-7
- 1 FIG. 777-10
- 4 FIG. 646-4HEX

- CLASSIC PEDESTAL STEERER/TAPERED
- DISHED DESTROYER WHEEL
- CHAIN & WIRE ROPE ASSY. W/HARDWARE
- RIGHT ANGLE CONDUIT MOUNTING PLATE
- PULL/PULL CONDUIT W/END FITTINGS
- RADIAL DRIVE WHEEL
- PEDESTAL MOUNTING BOLTS

FORWARD STATION:

- 1 FIG. 420-2-11T
- 1 FIG. 647ST-24-5
- 1 FIG. 77211
- 3 FIG. 799-2
- 1 FIG. 626ST-6ALNB
- 1 FIG. 621BR-6AL
- 2 FIG. 797-20
- 1 FIG. 676BR-14

- BULKHEAD STEERER W/THRU SHAFT BRAKE
- DISHED DESTROYER WHEEL
- CHAIN & WIRE ROPE ASSY. W/HARDWARE
- RIGHT ANGLE CONDUIT MOUNTING PLATE
- ARTICULOCK DOUBLE SHEAVE ASSY
- FLAT SINGLE SHEAVE ASSY
- PULL/PULL CONDUIT W/END FITTINGS
- MANGANESE BRONZE QUADRANT

